

This command sets the LAN parameters for this device.

DC4 DC4 ESC DC4 <n1> <n2> <function> <.... arguments ...>

Hexadecimal code: 14 14 1B 14 05 00 18 *arguments*

arguments must be ASCII test:

```
{
  HOST NAME=string ( max 15 crt )
  LOCATION= string ( max 30 crt )
  CONTACT= string ( max 30 crt )
  IP ASSIGN=[ARP,fixed,DHCP]
  IP ADDRESS=ip-address(*)
  NET MASK= ip-address(*)
  DEF.GATEWAY= ip-address(*)
  WORKGROUP= string ( max 15 crt )
  SMTP=[disabled,enabled]
  MAIL SERV.ADD.= ip-address(*)
  SENDER ADDRESS= string ( max 48 crt )
  DESTIN.ADDRESS= string ( max 48 crt )
}
```

arguments must start with the character '{' and must end with the character '}'

Each argument must be in one line.


If one argument is missing will be used the default one.

(*) the *ip-address* fields must be the format : DDD.DDD.DDD.DDD (example:
010.000.200.038)

arguments example:

```
{
HOST NAME=DEFAULT
LOCATION=No location
CONTACT=No contact
IP ASSIGN=fixed
IP ADDRESS=127.000.000.000
NET MASK=255.255.255.000
DEF.GATEWAY=000.000.000.000
WORKGROUP=P_NFFPS_TO
SMTP=disabled
MAIL SERV.ADD.=000.000.000.000
SENDER ADDRESS=No address
DESTIN.ADDRESS=No address
}
```

Command example:



```
00000000h: 14 14 1B 14 05 00 18 7B 0D 0A 48 4F 53 54 20 4E ; .....{..HOST N
00000010h: 41 4D 45 3D 44 45 46 41 55 4C 54 0D 0A 4C 4F 43 ; AME=DEFAULT..LOC
00000020h: 41 54 49 4F 4E 3D 4E 6F 20 6C 6F 63 61 74 69 6F ; ATION=No locatio
00000030h: 6E 0D 0A 43 4F 4E 54 41 43 54 3D 4E 6F 20 63 6F ; n..CONTACT=No co
00000040h: 6E 74 61 63 74 0D 0A 49 50 20 41 53 53 49 47 4E ; ntact..IP ASSIGN
00000050h: 3D 66 69 78 65 64 0D 0A 49 50 20 41 44 44 52 45 ; =fixed..IP ADDRE
00000060h: 53 53 3D 31 32 37 2E 30 30 30 2E 30 30 30 2E 30 ; SS=127.000.000.0
00000070h: 30 30 0D 0A 4E 45 54 20 4D 41 53 4B 3D 32 35 35 ; 00..NET MASK=255
00000080h: 2E 32 35 35 2E 32 35 35 2E 30 30 30 0D 0A 44 45 ; .255.255.000..DE
00000090h: 46 2E 47 41 54 45 57 41 59 3D 30 30 30 2E 30 30 ; F.GATEWAY=000.00
000000a0h: 30 2E 30 30 30 2E 30 30 30 0D 0A 57 4F 52 4B 47 ; 0.000.000..WORKG
000000b0h: 52 4F 55 50 3D 50 5F 4E 46 46 50 53 5F 54 4F 0D ; ROUP=P_NFFPS_TO.
000000c0h: 0A 53 4D 54 50 3D 64 69 73 61 62 6C 65 64 0D 0A ; .SMTP=disabled..
000000d0h: 4D 41 49 4C 20 53 45 52 56 2E 41 44 44 2E 3D 30 ; MAIL SERV.ADD.=0
000000e0h: 30 30 2E 30 30 30 2E 30 30 30 2E 30 30 30 0D 0A ; 00.000.000.000..
000000f0h: 53 45 4E 44 45 52 20 41 44 44 52 45 53 53 3D 4E ; SENDER ADDRESS=N
00000100h: 6F 20 61 64 64 72 65 73 73 0D 0A 44 45 53 54 49 ; o address..DESTI
00000110h: 4E 2E 41 44 44 52 45 53 53 3D 4E 6F 20 61 64 64 ; N.ADDRESS=No add
00000120h: 72 65 73 73 0D 0A 7D ; ress..}
```

The command example file is located in the SP40LanPar.zip file.

Refer to files : lanpar.bat, lanpar.hdr, lanpar.txt