



Installing DRAM Memory DIMMs on the Color Laser Printer


1. Ensure that the printer power switch is set to the OFF [O] position and disconnect the power cord from the wall outlet.



2. Turn thumbscrews on controller assembly counterclockwise until loose and gently pull controller assembly towards you to remove from printer.




3. Carefully insert a DRAM DIMM which is compatible with your printer into any available DRAM DIMM slot as shown below. When properly seated, gently push down on the DIMM until the white braces close onto the ends of the DIMM.





NOTE: To remove the DRAM DIMM, pull the white braces away from the ends of the DIMM until the DIMM snaps out of the slot.

4. Reinstall the controller assembly. Once firmly in place, push and hand tighten the thumbscrews in a clockwise direction.



5. Connect the power cord to the wall outlet and turn the printer power switch to the ON [I] position



◆ ◆ ◆