

# **Ethernet Network Interface Card (NIC) Installation in 21, 28, 32 and 40 Page-Per-Minute Laser Printers**

The information in this guide may change without notice. The manufacturer assumes no responsibility for any errors which may appear in this guide.

DEC, thickwire, thinwire, VMS, VT100, and ULTRIX are trademarks of Digital Equipment Corporation. UNIX is a registered trademark of AT&T. Ethernet is a trademark of XEROX. NetWare is a trademark of Novell Corp. AppleTalk, Chooser, and Macintosh are trademarks of Apple Computer Corp. Windows NT and Windows for Workgroups are trademarks of Microsoft Corporation. Portions copyright 1989, 1991, 1992, 1993 Regents of the University of California. All rights reserved. Used with permission. Portions of this work are derived from the Standard C Library, copyright 1992 by P.J. Plauger, published by Prentice-Hall, and are used with permission.

Copyright 200. All rights reserved. No part of the contents of this book may be transmitted or reproduced in any form or by any means without the written permission of the manufacturer.

## About this Manual

This manual is organized in the following chapters and appendices:

### Chapter 1 Introduction

This chapter describes the functionality and physical characteristics of the Ethernet Network Interface Card (NIC). It also provides information about the handling of ESD-sensitive parts.

### Chapter 2 Ethernet Network Interface Card (NIC) Installation in 21 Page-Per-Minute Printers

This chapter explains the procedure for installing the Ethernet Network Interface option in 21 page-per-minute laser printers. Connection of the Ethernet network source cable is also discussed.

### Chapter 3 Ethernet Network Interface Card (NIC) Installation in 28 Page-Per-Minute Printers

This chapter explains the procedure for installing the Ethernet Network Interface option in 28 page-per-minute laser printers. Connection of the Ethernet network source cable is also discussed.

### Chapter 4 Ethernet Network Interface Card (NIC) Installation in 32 and 40 Page-Per-Minute Laser Printers

This chapter explains the procedure for installing the Ethernet Network Interface option in 32 and 40 page-per-minute laser printers. Connection of the Ethernet network source cable is also discussed.

### Chapter 5 Ethernet Network Interface Configuration

This chapter will familiarize you with the configuration requirements for your NIC in a variety of different environments to include AppleTalk, Local Area Transport (LAT), Netware and TCP/IP.

### Appendix A Customer Support

This chapter discusses sources of help, information and technical support.

## Appendix B Troubleshooting

This appendix offers various troubleshooting procedures and technical support advice.

## Appendix C Frequently Used Commands

This appendix lists some of the most frequently-used commands of the Print Server command set. More information about the command set, including additional options, can be found in the Print Server Reference Manual on the Electronic Library CD-ROM.

◆ ◆ ◆





# Contents

---

## Contents v

---

## Chapter 1

---

### Introduction 1-1

About this Chapter 1-2

Product Description 1-2

Physical Characteristics 1-2

Handling ESD-Sensitive Parts 1-3

---

## Chapter 2

---

### Ethernet Network Interface Card (NIC) Installation in 21 Page-Per-Minute Printers 2-1

About this Chapter 2-2

Ethernet Network Connectivity in 21 Page-Per-Minute Printers 2-2

Installing the Ethernet Network Interface on the Controller Assembly 2-3

Replacing the Printer Side Cover 2-5

---

## Chapter 3

---

### Ethernet Network Interface Card (NIC) Installation in 28 Page-Per-Minute Printers 3-1

About this Chapter 3-2

Ethernet Network Connectivity in 28 Page-Per-Minute Printers 3-2

Installing the Ethernet Network Interface on the Controller Assembly 3-4

Replacing the Printer Side Cover 3-5

---

## Chapter 4

---

### Ethernet Network Interface Card (NIC) Installation in 32 and 40 Page-Per-Minute Laser Printers 4-1

About this Chapter 4-2

Ethernet Network Connectivity in 32 and 40 Page-Per-Minute Printers 4-2

Installing the Ethernet Network Interface on the Controller Assembly 4-4

---

## Chapter 5

---

### Ethernet Network Interface Configuration 5-1

About this Chapter 5-2

Control Panel Settings 5-2

Net 1 Setup 5-2

Net 2 Setup 5-3

Getting Started 5-5

EZWebCon Configuration 5-5

Incoming Logins 5-5

Services 5-6

AppleTalk Configuration 5-6

Macintosh Services 5-6

AppleTalk Zones 5-7

AppleTalk Host Troubleshooting 5-7

LAT Configuration 5-7

Printing Directly to a Port 5-7

LAT Host Troubleshooting 5-8

NetWare Configuration 5-8

Configuring Your NIC 5-8

Creating Print Queues Using NetWare Administrator Quick Setup 5-9

Creating NDS Print Queues Using PCONSOLE 5-9

NetWare Host Troubleshooting 5-10

TCP/IP Configuration 5-11

- Setting the IP Address 5-11
  - Printer's control panel 5-11
  - Using a Directed Ping Packet 5-11
  - Using a BOOTP, DHCP, or RARP Reply 5-12
- Notes About LPR 5-12
- LPR on Generic UNIX Hosts 5-12
  - LPR on AIX Hosts 5-13
  - LPR on HP Hosts 5-13
  - LPR on SCO UNIX Hosts 5-14
  - LPR on Windows NT 3.51 5-14
  - LPR on Windows NT 4.0 5-15
- RTEL Functionality 5-15
- Unix Host Troubleshooting 5-16

---

## Appendix A

---

### Customer Support A-1

**About this Chapter A-2**

**Obtaining Help and Information A-2**

- Your Point of Purchase A-2
- Your Application Vendor A-2

**Technical Support A-2**

**A-2**

---

## Appendix B

---

### Troubleshooting B-1

**About this Appendix B-2**

**Power-Up Troubleshooting B-2**

**Printing Problems B-3**

**BOOTP Troubleshooting B-3**

**DHCP Troubleshooting B-4**

**RARP Troubleshooting B-4**

**PostScript Problems B-4**

**Bitmap Graphics B-5**

**Technical Support B-5**

---

## Appendix C

---

### Frequently Used Commands C-1

[About this Appendix C-2](#)

[Server Commands C-3](#)

[Protocol Commands C-6](#)



# Chapter 1

## Introduction

### In this Chapter . . .

- “About this Chapter” on page 1-2
- “Product Description” on page 1-2
- “Physical Characteristics” on page 1-2
- “Handling ESD-Sensitive Parts” on page 1-3

## About this Chapter

This chapter describes the functionality and physical characteristics of the Ethernet Network Interface Card (NIC). It also provides information about the handling of ESD-sensitive parts.

## Product Description

The Ethernet Network Interface Card (NIC) is an internal multiprotocol print server that provides shared network access to the printer for a variety of network protocols and operating systems. The NIC supports the following protocols: TCP/IP, AppleTalk (EtherTalk), Local Area Transport (LAT), and IPX (NetWare). The NIC can queue multiple pending jobs and service those jobs in the order that they are received from the hosts.


## Physical Characteristics

The front panel of the Ethernet NIC has a TEST/RESET button and four LEDs.

---

**NOTE:** The Ethernet NIC card is available in two configurations. One configuration contains an RJ45 port for 10Base-T or 100Base-T connections. The second configuration contains the RJ-45 port and a BNC connector for 10Base-2 connections. The illustration below depicts the latter configuration.

---



Number	Description
1	BNC port - for 10Base-2 network connections.
2	TEST/RESET button - when pressed briefly while powering up the unit, returns the NIC to its original factory default configuration.
3	NIC LED - blinks yellow quickly at power on and slowly during normal operation to show unit is functioning.
4	BNC - Lights solid green to when a valid BNC network is attached to the NIC.
5	RJ45 port - for 10Base-T or 100Base-T network connections.

Number	Description
6	NET LED - blinks yellow to reflect network activity.
7	BASE-T LED - lights solid green to indicate a valid 10Base-T or 100Base-T connection.

**NOTE:** Once installed, the Ethernet NIC will automatically sense the network connection and will automatically configure the RJ-45 or BNC connection accordingly.

## Handling ESD-Sensitive Parts



### CAUTION:

Many electronic parts use parts that are known to be sensitive to electrostatic discharge (ESD). To prevent damage to ESD-sensitive parts, follow the instructions below in addition to all the usual precautions, such as turning off power before removing logic boards:

- Keep the ESD-sensitive part in its original shipping container (a special “ESD bag”) until you are ready to install the part into the machine.
- Make the least-possible movements with your body to prevent an increase of static electricity from clothing fibers, carpets, and furniture.
- Put an optional ESD wrist strap on your wrist. Connect the wrist band to the system ground point. This discharges any static electricity in your body to the machine.
- Hold the ESD-sensitive NIC by its edge connector cover; do not touch its pins. If you are removing a pluggable module, use the correct tool.
- Do not place the ESD-sensitive NIC on any metal surface; if you need to put down the ESD-sensitive part for any reason, first put it into its special bag.
- Metal surfaces are electrical grounds. They increase the risk of damage because they make a discharge path from your body through the ESD-sensitive part. (Large metal objects can be discharge paths without being grounded.)
- Prevent ESD-sensitive parts from being accidentally touched by other personnel.
- Be extra careful working with ESD-sensitive parts when cold weather heating is used because low humidity increases static electricity.





## Chapter 2

# Ethernet Network Interface Card (NIC) Installation in 21 Page-Per-Minute Printers

### In this Chapter . . .


- “About this Chapter” on page 2-2
- “Ethernet Network Connectivity in 21 Page-Per-Minute Printers” on page 2-2
- “Installing the Ethernet Network Interface on the Controller Assembly” on page 2-3
- “Replacing the Printer Side Cover” on page 2-5

## About this Chapter


This chapter explains the procedure for installing the Ethernet Network Interface option in 21 page-per-minute laser printers. Connection of the Ethernet network source cable is also discussed.

## Ethernet Network Connectivity in 21 Page-Per-Minute Printers


1. Carefully review the safety precautions in the front of this guide before starting this installation procedure.
2. Ensure that the printer power switch is set to the OFF [ O ] position and unplug the power cord from the AC outlet.



3. Loosen the thumbscrews at the top and bottom of the left side cover by turning them in a counter-clockwise direction.




4. Slide the cover towards the rear of the printer and then downwards to remove it.



## Installing the Ethernet Network Interface on the Controller Assembly

**NOTE:** It is not necessary to remove the controller from your printer to complete the installation. For clarity, the following illustrations depict a controller removed from the printer. When facing the front of the controller as shown below, network port 1 is on the right and network port 2 is on the left. However, when installed in the printer, network port 1 is on the bottom and network port 2 is on top. In the following few steps, an Ethernet network interface is being installed in network port 2.

1. Turning thumbscrews counter-clockwise, remove the blank metal plate covering one of the available network ports on the controller bracket.




---


**NOTE:** There is a wide variety of network and interface options for your printer. Although the installation procedures for all these options are the same, the appearance of your interface may vary slightly from that shown in the following illustrations.

---

1. While aligning the front bracket of the NIC assembly to the two respective thumbscrews on the controller assembly bracket, firmly seat the 80-pin male connector on the underside of the NIC to the 80-pin female connector on the controller assembly.




2. Secure the NIC assembly to the controller bracket by tightening the two smaller thumbscrews in a clockwise direction.






## Replacing the Printer Side Cover


1. Insert the top part of the left side cover into the printer. Ensure the locking tab aligns with the hole in the printer's side.




2. Slide the side cover towards the front of the printer to install it.



3. Tighten both thumbscrews in a clockwise direction.



4. Connect the appropriate network cable. For 10Base/100Base-T environments, connect a twisted pair Ethernet cable to the RJ45 connector. For 10Base-2 environments, connect a thin coaxial Ethernet cable to the BNC connector.
5. Connect the power cord to the wall outlet and turn the printer power switch to the ON [ I ] position.



---

**NOTE:** Before supplying power to the printer, be sure that only 1 physical Ethernet port is used.

---

---

**NOTE:** The BNC and BASE-T LEDs indicate good network connection. The OK LED gives information about what the NIC is doing; for example, when code is being downloaded as the unit boots, the LED will blink green quickly.

---

6. Allow 45 seconds for the unit to fully boot. The BNC or BASE-T green LED will be lit if there is a valid connection to the network, and the NET yellow LED should blink slowly to show the unit is functioning properly.
7. Print a Test page by pressing the TEST/RESET button.

---

**NOTE:** If the Power LED does not blink slowly, refer to Appendix B, Troubleshooting.

---

Installation of the Ethernet Network Interfation Card (NIC) in your printer is now complete.  
Please proceed to [Chapter 5 Ethernet Network Interface Configuration](#) .





# Chapter 3

## **Ethernet Network Interface Card (NIC) Installation in 28 Page-Per-Minute Printers**

### **In this Chapter . . .**


- “About this Chapter” on page 3-2
- “Ethernet Network Connectivity in 28 Page-Per-Minute Printers” on page 3-2
- “Installing the Ethernet Network Interface on the Controller Assembly” on page 3-4
- “Replacing the Printer Side Cover” on page 3-5

## About this Chapter


This chapter explains the procedure for installing the Ethernet Network Interface option in 28 page-per-minute laser printers. Connection of the Ethernet network source cable is also discussed.

## Ethernet Network Connectivity in 28 Page-Per-Minute Printers


1. Carefully review the safety precautions in the front of this guide before starting this installation procedure.
2. Locate the recessed area near the top of the rear of the printer and pull on the recessed area to open the rear cover.




3. Ensure that the printer power switch is set to the OFF [ O ] position and disconnect the power cord from the wall outlet.



4. Remove the cover on the left side of the printer by first sliding the cover toward the rear of the printer, then pulling the bottom of the cover toward you and then down.



5. Remove the cover shield by first loosening the two thumbscrews in a counter-clockwise direction and then gently lifting up and pulling towards you.




6. Removal of the cover shield will expose the controller assembly.


## Installing the Ethernet Network Interface on the Controller Assembly

**NOTE:** It is not necessary to remove the controller from your printer to complete the installation. For clarity, the following illustrations depict a controller removed from the printer. When facing the front of the controller as shown below, network port 1 is on the right and network port 2 is on the left. However, when installed in the printer, network port 1 is on the bottom and network port 2 is on top. In the following few steps, an Ethernet network interface is being installed in network port 2.

1. Turning thumbscrews counter-clockwise, remove the blank metal plate covering one of the available network ports on the controller bracket.




2. While aligning the front bracket of the NIC assembly to the two respective thumbscrews on the controller assembly bracket, firmly seat the 80-pin male connector on the underside of the NIC to the 80-pin female connector on the controller assembly.



3. Secure the NIC assembly to the controller bracket by tightening the two smaller thumb-




screws in a clockwise direction.




## Replacing the Printer Side Cover


1. Replace the cover shield as shown and tighten the two thumbscrews.



2. Replace the side cover of the printer.



3. Connect the appropriate network cable. For 10Base/100Base-T environments, connect a twisted pair Ethernet cable to the RJ45 connector. For 10Base-2 environments, connect a thin coaxial Ethernet cable to the BNC connector.
4. Plug the power cord in the AC outlet and turn the printer power switch to the ON [ I ] position.



---

**NOTE:** Before supplying power to the printer, be sure that only 1 physical Ethernet port is used.

---

---

**NOTE:** The BNC and BASE-T LEDs indicate good network connection. The OK LED gives information about what the NIC is doing; for example, when code is being downloaded as the unit boots, the

---

LED will blink green quickly.

---

5. Allow 45 seconds for the unit to fully boot. The BNC or BASE-T green LED will be lit if there is a valid connection to the network, and the NET yellow LED should blink slowly to show the unit is functioning properly.
  6. Print a Test page by pressing the TEST/RESET button.
- 

**NOTE:** If the Power LED does not blink slowly, refer to Appendix B, Troubleshooting.

---

Installation of the Ethernet Network Interfaction Card (NIC) in your printer is now complete. Please proceed to [Chapter 5 Ethernet Network Interface Configuration](#) .





## Chapter 4

# Ethernet Network Interface Card (NIC) Installation in 32 and 40 Page-Per-Minute Laser Printers


- [“About this Chapter” on page 4-2](#)
- [“Ethernet Network Connectivity in 32 and 40 Page-Per-Minute Printers” on page 4-2](#)
- [“Installing the Ethernet Network Interface on the Controller Assembly” on page 4-4](#)

## About this Chapter


This chapter explains the procedure for installing the Ethernet Network Interface option in 32 and 40 page-per-minute laser printers. Connection of the Ethernet network source cable is also discussed.

## Ethernet Network Connectivity in 32 and 40 Page-Per-Minute Printers


1. Turn the printer power switch to the OFF [ O ] position.



2. Disconnect the power cord from the wall outlet.




3. Remove the controller from the printer by loosening the thumbscrews in a counterclockwise direction and pulling the controller towards you.



4. Turning thumbscrews counter-clockwise, remove one of the blank metal plates covering a network port access. Either expansion locations can be used.


### **Installing the Ethernet Network Interface on the Controller Assembly**

1. While aligning the front bracket of the NIC assembly to the two respective thumbscrews on the controller assembly bracket, firmly seat the 80-pin male connector on the underside of the NIC to the 80-pin female connector on the controller assembly.




**4-4** Ethernet Network Interface Card (NIC) Installation in 21, 28, 32 and 40 Page-Per-Minute Laser Printers  
**Installing the Ethernet Network Interface on the Controller Assembly**

2. Secure the NIC assembly to the controller bracket by tightening the two smaller thumb-screws in a clockwise direction.





3. Return the controller to the printer. Ensure that it is firmly seated in the printer and tighten thumbscrews in a clockwise direction.






4. Connect the appropriate network cable. For 10Base/100Base-T environments, connect a twisted pair Ethernet cable to the RJ45 connector. For 10Base-2 environments, connect a thin coaxial Ethernet cable to the BNC connector.


or



5. Connect the power cord to the wall outlet.



6. Turn the printer power switch to the ON [ I ] position.



---

**NOTE:** Before supplying power to the printer, be sure that only 1 physical Ethernet port is used.

---

---

**NOTE:** The BNC and BASE-T LEDs indicate good network connection. The OK LED gives information about what the NIC is doing; for example, when code is being downloaded as the unit boots, the LED will blink green quickly.

---

- 7.** Allow 45 seconds for the unit to fully boot. The BNC or BASE-T green LED will be lit if there is a valid connection to the network, and the NET yellow LED should blink slowly to show the unit is functioning properly.
- 8.** Print a Test page by pressing the TEST/RESET button.

---

**NOTE:** If the Power LED does not blink slowly, refer to Appendix B, Troubleshooting.

---

Installation of the Ethernet Network Interfaction Card (NIC) in your printer is now complete. Please proceed to ["Chapter 5 "Ethernet Network Interface Configuration](#) .



# Chapter 5

## Ethernet Network Interface Configuration

### In this Chapter . . .

- “About this Chapter” on page 5-2
- “Control Panel Settings” on page 5-2
- “EZWebCon Configuration” on page 5-5
- “Incoming Logins” on page 5-5
- “Services” on page 5-6
- “AppleTalk Configuration” on page 5-6
- “LAT Configuration” on page 5-7
- “NetWare Configuration” on page 5-8
- “TCP/IP Configuration” on page 5-11

## About this Chapter

This chapter will familiarize you with the configuration requirements for your NIC in a variety of different environments to include AppleTalk, Local Area Transport (LAT), Netware and TCP/IP.

## Control Panel Settings

When you install network options in the network card slots 1 and 2, the Network 1 and Network 2 control panel submenus appear within the Interface Menu. The interface submenu contains the settings relevant to the data input sources, interpreter selection, etc.

Menu		
	Paper Menu	
	Interface Menu	
		Port
		Parallel Setup
		Serial Setup
		Network 1 Setup
		Network 2 Setup
	PS Menu	
	PCL Menu	
	System Menu	
	Quality Menu	
	Functions	
	Flash Menu	
	Disk Menu	

### Net 1 Setup

This menu selection is used to configure the printer's Net 1 port.

---

**NOTE:** This entire Net 1 Setup menu tree is only visible when an optional network interface is installed in the Net 1 slot.

---

AVAILABLE SELECTIONS	INTERPRETER AUTO SWITCH ( <b>see Notes 1 and 3 below</b> ) PCL POSTSCRIPT 3
DEFAULT	AUTO SWITCH
	FORMAT ( <b>see Note 3 below</b> ) NORMAL BINARY RAW
DEFAULT	RAW
	NETWORK CHANNEL NETWARE OFF ON
DEFAULT	ON

	DEC LAT OFF ON
DEFAULT	ON
	APPLETALK OFF ON
DEFAULT	ON
	TCP/IP OFF ON
DEFAULT	ON
	NETWORK ADDRESS
DEFAULT	XXXXXXXXXX (see Note 4 below)
	IP ADDRESS
DEFAULT	XX.XX.XX.XX (see Note 5 below)
	SUBNET MASK
DEFAULT	XX.XX.XX.XX (see Note 5 below)
	DEFAULT ROUTER
DEFAULT	XX.XX.XX.XX (see Note 5 below)
	LPD BANNER OFF ON
DEFAULT	OFF
	DHCP OFF ON
DEFAULT	OFF
	NETWORK FRAME AUTO SENSE 802.3 ETHERNET II 802.2 SNAP 802.2
DEFAULT	AUTO SENSE

- 
- NOTE:**
1. Only available as a menu selection if an IPDS option is installed in the printer.
  2. Always available as a menu selection.
  3. If AUTO SWITCH is selected the FORMAT selection will automatically be RAW.
  4. This selection reflects the Macintosh network address
  5. This is a free format entry that requires your input.
- 

### Net 2 Setup

This menu selection is used to configure the printer's Net 2 port.

**NOTE:** This entire Net 2 Setup menu tree is only visible when an optional network interface is installed in the Net 2 slot.t.

AVAILABLE SELECTIONS	INTERPRETER AUTO SWITCH (see Notes 1 and 3 below) PCL POSTSCRIPT 3
DEFAULT	AUTO SWITCH
	FORMAT (see Note 3 below) NORMAL BINARY RAW
DEFAULT	RAW
	NETWORK CHANNEL NETWARE OFF ON
DEFAULT	ON
	DEC LAT OFF ON
DEFAULT	ON
	APPLETALK OFF ON
DEFAULT	ON
	TCP/IP OFF ON
DEFAULT	ON
	NETWORK ADDRESS
DEFAULT	XXXXXXXXXXXX (see Note 4 below)
	IP ADDRESS
DEFAULT	XX.XX.XX.XX (see Note 5 below)
	SUBNET MASK
DEFAULT	XX.XX.XX.XX (see Note 5 below)
	DEFAULT ROUTER
DEFAULT	XX.XX.XX.XX (see Note 5 below)
	LPD BANNER OFF ON
DEFAULT	OFF
	DHCP OFF ON
DEFAULT	OFF

	NETWORK FRAME AUTO SENSE 802.3 ETHERNET II 802.2 SNAP 802.2
DEFAULT	AUTO SENSE
	QUEUE SCAN RATE 1 - 255
DEFAULT	1

- 
- NOTE:**
1. Only available as a menu selection if an IPDS option is installed in the printer.
  2. Always available as a menu selection.
  3. If AUTO SWITCH is selected the FORMAT selection will automatically be RAW.
  4. This selection reflects the Macintosh network address
  5. This is a free format entry that requires your input.
- 

## Getting Started

It is important to consider the following points before logging into and configuring the NIC:

- The NIC's IP address must be configured before any TCP/IP functionality is available. See ["Setting the IP Address" on page 5-11.](#)
- There are two important passwords on the NIC: the privileged password and the login password.

Changing any server, service, or port setting requires privileged user status. The default privileged password is **system**.

The login password is required for remote console logins. The default login password is **access**.

- 
- NOTE:** If you would like to change either the privileged or login password, either use EZWebCon or refer to the [Print Server Reference Manual located on the CD-ROM](#)
- 

## EZWebCon Configuration

The EZWebCon configuration software is the recommended way to configure the NIC. EZWebCon is a graphical user interface which guides first time users through the initial configuration process and allows experienced users to update and change any configurable parameters.

The EZWebCon software is located on the CD-ROM that came with your printer. All instructions for installing EZWebCon are listed in the README file. For assistance once EZWebCon is running, refer to the EZWebCon on-line help.

## Incoming Logins

Incoming logins made via EZWebCon can be used to configure the server. Incoming LAT and TCP/IP logins can also be made using LAT and TCP/IP commands.

Incoming Telnet connections are enabled by default. To change this setting, use the **Define Server Incoming** command described in the *Command Reference* chapter of the *Print Server Reference Manual* located on CD-ROM.

Incoming logins do not prompt for a login password; therefore, you may wish to disable them. If it is undesirable to disable incoming logins, the Server can be configured to prompt for a password with the **Define Server Incoming Password Enabled** command.

## Services

With few exceptions, a **service** must be created before print queues can be configured on the NIC. A service is a resource accessible to network hosts. The following 2 default services are available once the NIC has booted:

PRQ_XXXXXX_TEXT	Used for text print jobs
PRQ_XXXXXX_BIN	Used for binary print jobs, such as plotter, PCL or PostScript files.

---

**NOTE:** The default service names based on the NIC's server name (PRQ\_XXXXXX), with the x's being the last six digits of the NIC's Ethernet address. The service names must be no more than 13 characters. For LPR the default queue names of PRQ\_TEXT, PRQ\_BIN can be used.

---

If you need to modify a default service, see the *Server Configuration* chapter of the *Print Server Reference Manual* located on the CD-ROM. Be sure to reboot after configuring services so that the changes take effect.

## AppleTalk Configuration

The EZWebCon configuration software is the easiest way to configure the NIC. The following sections cover other print configuration methods for AppleTalk hosts.

---

**NOTE:** The NIC needs an IP address before you can use EZWebCon. See ["Setting the IP Address" on page 5-11](#).

---



---

**NOTE:** Macintosh systems that do not support EtherTalk will need either an Ethernet card or a LocalTalk-to-EtherTalk router to use the NIC.

---



---

**NOTE:** MacOS 8.1 can also print via LPD. See the *Print Server Reference Manual* located on CD-ROM for configuration instructions.

---

## Macintosh Services

Before attempting to print from a Macintosh, ensure that AppleTalk and PostScript are both enabled on at least one service. Once the service is configured, it will appear in the Chooser in the same zone as the NIC. Select the service in the Chooser and complete the appropriate setup options. Then close the Chooser window and print a test page of text to the Macintosh service.



## AppleTalk Zones

If there is a router on the network, the NIC will appear in the default zone specified by the router. To change the default zone, enter the **Define Protocol AppleTalk Zone** command and reboot the printer.

If the NIC is attached to a network without an AppleTalk router, all AppleTalk devices (including the NIC) will appear in the default zone in the Chooser.

---

**NOTE:** If no router is present on the network, the NIC will not accept AppleTalk print jobs for 60 seconds after booting.

---

### AppleTalk Host Troubleshooting

Area to Check	Explanation
The printer is available to be selected in the Chooser	Make sure the printer is in the right zone.

## LAT Configuration

The EZWebCon configuration software is the easiest way to configure the NIC. The following sections cover other print configuration methods for LAT hosts.

---

**NOTE:** The NIC needs an IP address before you can use EZWebCon. See [“Setting the IP Address” on page 5-11](#).

---

LAT print queues can be created by printing to a port or printing to a service. Printing directly to a port requires no NIC configuration.

---

**NOTE:** Printing directly to a port is the easiest method for printing to the NIC. If you would like instructions for printing to a service, see the Print Server Reference Manual on the CD-ROM.

---

### Printing Directly to a Port

1. Create a LAT application port that references the NIC port.

```
$ RUN SYS$SYSTEM:LATCP
LATCP> CREATE PORT LTAnnn/APPLICATION
LATCP> SET PORT LTAnnn/NODE=PRQ_XXXXXX/PORT=Port_n
LATCP> EXIT
```

2. Create and start a print queue that uses the LAT application port.

```
$ INITIALIZE/QUEUE/START/ON=LTAnnn: /PROCESSOR=LATSYM
/RETAIN=ERROR queue_name
```

3. Add the commands to the SYS\$MANAGER:LAT\$STARTUP.COM file so the required LAT devices will be recreated after each host reboot.

**NOTE:** LAT terminal device characteristics may have to be changed to correctly print certain files. See your VMS documentation for more information.

- Print to the queue.

```
$ PRINT/QUEUE=queue_name filename.txt
```

*LAT Host Troubleshooting*

By default, the LAT error message codes on the host are not translated into text error messages. If a LAT job fails and appears in the queue with an eight-digit hex result code, the code can be translated by issuing the following commands:

```
$ SHOW QUEUE/FULL/ALL queue_name
(note the error code nnnnnnnn)
$ SET MESSAGE SYS$MESSAGE:NETWRKMSG.EXE
$ EXIT %Xnnnnnnnn
```

Area to check	Explanation
The specified node name matches the server's node name	Use the <b>Show Server</b> command.
The specified port name matches the port's name	Use the <b>List Port 1</b> command.

### NetWare Configuration

The EZWebCon configuration software is the easiest way to configure the NIC. The following sections cover other print configuration methods for NetWare hosts.

**NOTE:** The NIC needs an IP address before you can use EZWebCon. See the [“Setting the IP Address” on page 5-11](#) for instructions.

This chapter explains creating NDS print queues with NetWare Administrator and with the PCONSOLE Quick Setup option. To create NDS print queues, you must be running NetWare version 4.x with NDS capabilities.

If you are running NetWare versions 2.x, 3.x, or version 4.x with bindery emulation, you may configure bindery print queues using QINST (bindery only) or PCONSOLE. For more information, see the *NetWare* chapter of the *Print Server Reference Manual*, located on CD-ROM.

### Configuring Your NIC

- Define the directory service tree in which the NIC is located.

```
Local>> DEFINE PROTOCOL NETWARE DSTREE foodco
```

**NOTE:** For an explanation of the structure of the NetWare Directory Service tree, see your host documentation.

2. Define the directory service context in which the NIC is located.

```
Local>> DEFINE PROTOCOL NETWARE DSCONTEXT ou=kiwi.ou=exotic.o=fruit
```

3. Enter the **List Protocol NetWare Access** command to ensure that at least one of the file servers in the directory service tree is in the access list.
4. If desired file server is not in the access list, add it.

```
Local>> DEFINE PROTOCOL NETWARE ACCESS fileserver
```

### Creating Print Queues Using NetWare Administrator Quick Setup

The NetWare Administrator management utility allows you to manage network resources, such as queue-based print services, in a tree structure. You can either use the Quick Setup option or individually create printing-related objects.

To create a print queue with the Quick Setup option.

---

**NOTE:** NetWare Administrator can be used for both NDS and bindery print queues.

---

1. Start NetWare Administrator.
2. In the **Directory Tree** windows, navigate to and select the context in which you want to install the printer.
3. From the Menu Bar, select **Tools: Print Services Quick Setup**.
4. In the **Print Server Name** field, enter the name of your NIC (viewable by entering the **Show Server** command at the Local> prompt).
5. In the **Printer Name** field, enter the name of the desired print *service* configured on your NIC.
6. In the **Print Queue Name** field, enter the name of the print queue to create. The name should be meaningful to you; it will not affect the NIC's configuration.
7. Click **Create**.

### Creating NDS Print Queues Using PCONSOLE

1. Log in as Admin on the file server you will be changing.
2. Type **PCONSOLE** at the F: prompt to start the utility.
3. From the main menu choose **Quick Set-Up**.
4. PCONSOLE will prompt you for information with which to configure the print queue.
5. The print server name is the name of your NIC (PRQ\_XXXXXX). The new printer name is the service name (PRQ\_XXXXXX\_YY). The new print queue can be any name. The print queue volume is the name of the file server from which the printer receives print requests. The remaining fields can be left in their default settings.
6. Press the **F10** key to save the print queue information.
7. Reboot the printer.

## NetWare Host Troubleshooting

Netware Host Troubleshooting (Bindery Mode)	
Area to Check	Explanation
The server and queue names match the print server and service name	Use PCONSOLE to check.
NetWare access table	Scanning too many file servers can cause a delay between jobs. Configure the access list to only scan for jobs on the file servers of interest.

Netware Host Troubleshooting (NDS)	
Area to Check	Explanation
NetWare access table	By default, only local (non-routed) file servers are scanned for queues.
The login password on the NIC and the queue password on the file server	The passwords must match or the NIC will not be able to log into the file servers to scan for jobs.
The print server has successfully attached to the queue	Type <b>NETSTAT</b> at the Local> prompt. This will display information about fileservers, printers, and queues that the print server has found. If a queue is in JobPoll, the print server has successfully attached to the queue.
The DSTree, DSContext, and DSLicense	Type <b>Show Protocol NetWare NDS</b> . This command shows the tree and the context that you have configured, a failure code, and an NDS error code for each server.  DSTree is the directory service tree on which the print server is located. DSContext is the context where the print server is located; it must match the context on the file server (The DSContext must be of the following form: ou=fruit.0=exotic). DSLicensed should be yes.
Printer and queue changes have propagated through the NDS tree	It may take a few minutes for the changes to propagate. If the print server doesn't attach, reboot the server.

NDS Printing Errors		
Bit	Failure Code Meaning	Remedy
1	NIC out of memory	Cycle power. Disable unused protocols and/or remove fileservers without print queues from the NetWare access list.
2, 3	Unexpected response from file server	Report the problem to Technical Support.

NDS Printing Errors		
Bit	Failure Code Meaning	Remedy
4	No printers found for the NIC	Ensure that there are printers for the print server, and the printer names match the service names on the print server.
5	No printer queue found	Ensure that the printers have associated queues.
6	Login failed	Ensure there is a print server object configured with the same name as the print server.
7	Authentication failed	Ensure the print server login password is the same as the print server object password. If the print server is using the default password (access) then there should be no password for the print server object.
8	NIC cannot attach to queue	Check the NDS partitions, replicas, and volumes to ensure the file server where the queue lives has the correct information about the NIC and printers.

## TCP/IP Configuration

The EZWebCon configuration software is the easiest way to configure the NIC. The following sections cover other print configuration methods for TCP/IP hosts.

---

**NOTE:** The NIC needs an IP address before you can use EZWebCon. See [“TCP/IP Configuration” on page 5-11](#) for instructions.

---

The NIC provides two major methods of printing via TCP/IP: Berkeley remote LPR and RTEL host software.

### Setting the IP Address

The NIC's IP address must be configured before any TCP/IP functionality is available.

To set the IP address, use one of the following methods: printer's control panel, EZWebCon, a directed Ping packet, a BOOTP, DHCP, or RARP reply, or commands entered at the command line (Local>) interface. Some of these options are discussed in the following sections. For command line configuration, see the *Getting Started* chapter of the *Print Server Reference Manual*.

#### Printer's control panel

Refer to the printer *User Manual* for setting the IP address via the control panel.

#### Using a Directed Ping Packet

1. Create an entry in the host's ARP table that contains the NIC's IP and hardware addresses.
2. Ping the NIC. If no other node is using the IP address, the NIC will use it.
3. To save the IP address, Telnet to the NIC and use the **Define Server IPaddress** command.

### Using a BOOTP, DHCP, or RARP Reply

At boot time a host-based DHCP, BOOTP, or RARP server can respond to an NIC request for an available IP address. For information about configuring the DHCP, BOOTP, or RARP server, see the host documentation.

### Notes About LPR

There are four important things to note about the LPR printing method:

1. Because of the way the LPR protocol is typically implemented on the host, the processing options and banner page are sent after the job data itself. **The NIC will print a banner page at the end of a job, and cannot support most of the LPR options.** If it is necessary to have the banner page at the beginning of the printout, install and use the RTEL software. If banners are not needed, they can be disabled.
2. The NIC cannot print multiple copies of the print job when using the “-#x” lpr option.
3. If two queues on the print host refer to two services on the same NIC, they must use separate spooling directories.
4. No special purpose input or output filters can be used when printing via LPR. If this functionality is necessary, use the named pipe interface program in the RTEL print queue configuration software.

### LPR on Generic UNIX Hosts

The Berkeley remote printing system is supported on many machines, and is simple to configure.

This section describes how to configure LPR print queues on generic UNIX hosts such as SUN hosts. There are slight variations in LPR configuration for AIX, HP, SCO, Solaris, ULTRIX, and Windows NT hosts. After reading this section, refer to the following sections for further configuration information.

1. Start by adding the NIC name and IP address to the **/etc/hosts** file:

```
xxx.xxx.xxx.xxx      PRQ_XXXXXX
```

2. Add the host print queue name into **/etc/printcap**, and then specify the remote node name (the host name of the NIC) and the service name on the NIC. For example:

```
prq_prt|Printer on LAB NIC:\
:rm=PRQ_XXXXXX:\
:rp=PRQ_XXXXXX_BIN:\
:sd=/usr/spool/lpd/PRQ_prt:
```

The punctuation shown is required, and no extra spaces should be added. This will create a host queue named **prq\_prt**. The **rm** parameter is the name of the NIC in the host's address file, the **rp** parameter is the name of the service as it exists on the NIC, and the **sd** parameter specifies the name of a directory used to hold temporary spooling files.

3. Create a world-writable spooling directory using the **mkdir** command.

```
# mkdir /usr/spool/lpd/prq_prt
# chmod 777 /usr/spool/lpd/prq_prt
```

4. If desired, use the **mx** option to allow unlimited size files to be printed and the **sh** option to prevent header pages from being generated. See the host's documentation or man pages for more information on the format of the printcap file and how to create the spool directory.
5. Print to the queue using normal lpr commands:

```
% lpr -Pprq_prt /etc/hosts
```

### LPR on AIX Hosts

LPR has only been tested on AIX versions 3.2 and higher. The System Management Interface Tool (SMIT) allows you to enable LPD printing and create print queues.

To create a print queue:

1. At the host prompt type *smit*.
2. Choose **Print Spooling**.
3. Choose **Manage Print Server** and **Start the Print Server Subsystem (lpd daemon)**.
4. In the Start the Print Server Subsystem dialog box, type *both* in the first field. The message "The lpd subsystem has been started" will appear. Click **Done**.

To add a print queue:

1. From the main window choose **Print Spooling**.
2. Choose **Manage Print Server** and **Manage Print Queues**.
3. Choose **Add a print queue**.
4. From the dialog box that appears choose **remote**.
5. From the next dialog box choose **Remote Printing**.
6. The **Add a Standard Remote Print Queue** dialog box will appear. Enter the information in each field.

A dialog box will appear with the message "Added print queue **prq\_prt**."

---

**NOTE:** If you are unable to use SMIT, see the Print Server Reference Manual for UNIX commands for setting up print queues.

---

7. Print to the queue using normal lp syntax.

```
% lp -dprq_prt filename
```

### LPR on HP Hosts

The System Administration Manager (SAM) allows you to create print queues.

---

**NOTE:** If you are unable to use SAM, the Print Server Reference Manual located on the CD-ROM described UNIX commands that can be used to set up print queues.

---

To create a print queue:

1. At the HP prompt type *sam*.
2. From the main application window choose **Printers and Plotters**.
3. Choose **Printers/Plotters** from the Printers and Plotters window.
4. In the pull-down menu select **Remote Printer/Plotter** from the **Actions** menu.
5. The Add Remote Printer window will appear. SAM will prompt you for the printer name, remote system name, remote printer name, remote cancel model, and remote status model.

---

**NOTE:** Printer names on HP hosts are limited to 13 characters. The NIC text service name will be too long, so you will have to rename the NIC.

---

### *LPR on SCO UNIX Hosts*

LPR is supported in SCO V3.2 release 4 with TCP/IP Version 1.2 and greater.

To configure a print queue using LPR:

1. Issue the **mkdev rlp** command. This will install the Berkeley remote printing files and executable programs.

---

**NOTE:** The **mkdev rlp** command should only be done once or serious problems will occur. If this happens, contact SCO technical support.

---

2. Print to this queue using normal lp syntax.

```
# lp -dprq_XXXXXX_text filename
```

To create a remote printer:

1. Issue the **rlpconf** command.
2. Answer the questions that follow.
3. During initial configuration, the queue name must be the same as the remote printer name. However, you may change the queue name later by manually editing the printcap file.

### *LPR on Windows NT 3.51*

---

**NOTE:** This installation assumes that TCP/IP, Simple TCP/IP, and Microsoft TCP/IP printing have been installed on Windows NT.

---

1. Open the NT Print Manager; its icon is located in the **Main** window on the desktop. In the **Printer** menu, choose **Create Printer**.
2. In the **Printer Name** field, enter the name of the queue on the NT host.
3. Click the **Driver** menu arrow and select the required printer driver from the pull-down menu. Enter a description string in the **Description** field if desired.

---

**NOTE:** If the printer driver isn't already installed, click the "Other..." from the driver list and supply the location of the printer's Windows NT 3.51 driver.

---



4. If applicable, choose the **Share this printer on the network** option. (This is not recommended until the print queue is confirmed to be running properly.)
5. Click the **Print To** menu arrow to view its pull-down menu. Scroll to select the **OTHER** option. Choose **LPR Port** and click the **OK** button.
6. In the LPR dialog box, provide.
7. In the printer-specific dialog box that appears, fill out the necessary information and click **OK**.
8. If you'd like this printer to be the default printer, click the default menu arrow on the Print Manager's title bar and scroll to the printer's name.

---

**NOTE:** Verify that you have read/write permissions on the NTFS file system.

---

9. Test the printer.

### *LPR on Windows NT 4.0*

---

**NOTE:** This installation assumes that TCP/IP, Simple TCP/IP, and Microsoft TCP/IP printing have been installed on Windows NT.

---

1. Double-click the **Printers** icon in the Control Panel.
2. Double-click the **Add Printer** icon.
3. In the window that appears select **My Computer**. Click **Next**.
4. Select the **Add Port** button. Click **Next**.
5. Select **LPR Port**.
6. Click **New Port**.
7. In the following window enter the name or address of the NIC and the service name.
8. Select the manufacturer and printer type.
9. Enter the queue name.
10. If applicable, choose **Shared** and select the type of operating system that the printer will be working with. (This is not recommended until the print queue is confirmed to be working.)
11. Test the printer.

### **RTEL Functionality**

If the LPR method of printing is not adequate for an application (for example, if you need banners before jobs, or more flexibility), configure the RTEL software on the host. After installing the software configuring the connections to the NIC, you can use normal UNIX print commands and queue utilities such as `lpc` and `lpstat`.

---

**NOTE:** RTEL binaries are provided for many systems. Source code is also provided for use on non-supported systems.

---

To print using special formatting or using third-party software packages, you may have to create “print pipes” on the host. The RTEL software provides this functionality by providing a UNIX named-pipe interface.

To recreate the RTEL source files:

1. Copy the file RTEL\_SRC.TAR from the distribution media to the UNIX host. Ensure that a binary copy is performed.
2. Untar the archive.
3. See the README files in the created directories that describe the contents of the RTEL distribution and man pages that describe the actual software functionality.

### Unix Host Troubleshooting

TCP Troubleshooting	
Area to Check	Explanation
The NIC's IP address and name are entered in the host file	Telnet to the NIC using the name in the host file and verify that the NIC name is resolvable and that the NIC is reachable via the network.
Jobs that appear in the host queue reach the NIC	From within the LPC administrative utility, enter these commands to clear and reset the host queue: <b>abort queue_name</b> <b>clean queue_name</b> <b>enable queue_name</b> <b>start queue_name.</b>



# Appendix A

## Customer Support

### In this Chapter . . .

- “About this Chapter” on page A-2
- “Obtaining Help and Information” on page A-2
- “Technical Support” on page A-2

## About this Chapter

This chapter discusses sources of help, information and technical support.

## Obtaining Help and Information

Several sources of help and information are available, depending on the type of help you need:

### Your Point of Purchase

Your local vendor from whom you purchased this printer may be best equipped to help you. Your vendor has specially trained service technicians available to answer questions and the equipment to analyze your printer problems.

### Your Application Vendor

Often, “printing” problems have more to do with the application being used than with the printer. In this case, the application manufacture is the best source of help.

## Technical Support

Technical Support is available world-wide. Please refer to your point of purchase for the appropriate contact in your area.

When calling for assistance, please have the following information readily available:

- Your phone number, fax number and shipping address.
- A description of the problem.
- The printer model.
- The type of host computer you are using.
- The type and version of operating system you are using.
- The application and version you are using.
- The interface you are using (e.g., network, parallel, serial).
- If using the network interface, the network protocol (TCP/IP, EtherTalk, IPX/SPX, NetBIOS/NetBEUI).
- The printer emulation you are using (e.g., PCL or PostScript).
- A printout of your printer's Configuration Summary. (Refer to your printer's *User* manual).
- If you have a printer hardware problem you cannot resolve, provide the error message displayed on the Control Panel. For a list of error messages, refer to your printer's *User* manual.

---

**NOTE:** To confirm that a problem is isolated to the Ethernet Network option, you may want to remove the Ethernet Network option from the printer and diagnose the printer using the User's Manual that came with your printer. If the condition persists, it can be assumed that the problem resides within the printer and not necessarily the Ethernet Network option.

---



# Appendix B

## Troubleshooting

### In this Chapter . . .

- “About this Appendix” on page B-2
- “Power-Up Troubleshooting” on page B-2
- “Printing Problems” on page B-3
- “BOOTP Troubleshooting” on page B-3
- “DHCP Troubleshooting” on page B-4
- “RARP Troubleshooting” on page B-4
- “PostScript Problems” on page B-4
- “Bitmap Graphics” on page B-5
- “Technical Support” on page B-5

## About this Appendix

This appendix offers various troubleshooting procedures and technical support advice.

## Power-Up Troubleshooting

There are several possible error situations if the unit does not display the welcome message or the LEDs do not flash:

Error Messages	
Message	Diagnosis/Remedy
Power-up diagnostic failure (hardware failure)	Note which LED is blinking and its color, then contact your dealer or Technical Support.
The NIC boots but does not try to load the Flash ROM code	Briefly press the Test button on the NIC's I/O panel. A NIC configuration page will be printed. <i>(To press the Test button, you will need a pointed object - e.g. paper clip.)</i>
Network Error: The ACT LED will blink yellow 2-3 times per second	A. Make sure the Ethernet network cable is properly connected and reboot the server.
	B. If option A fails to resolve the problem, reload Flash ROM. Refer to the Updating Software chapter of the <b>Print Server Reference Manual</b> .

## Printing Problems

Area to Check	Explanation
Physical connection	To test a non-PostScript printer use the <b>Test Port 1 Count 100</b> command. This command will send 100 lines of test data to the printer.
Service characteristics	Use the <b>Show Service Local Characteristics</b> command from a network login to see if the desired service is available and to verify that the appropriate protocols are enabled on the service.
The IP address	The IP address must be unique on the network. Many problems will occur when there are duplicate IP addresses on the network.
Queue Status and Port counters	Use the <b>Monitor Queue</b> command to ensure queue entries appear in the job list. If an entry does not appear, refer to the appropriate host section in this Appendix. Use the <b>Monitor Port n Counters</b> command to verify that the counter is incrementing with each job. If it is not, verify the connection between the NIC and the printer.

## BOOTP Troubleshooting

If the BOOTP request is failing and you have configured your host to respond to the request, check these areas:

Area to Check	Explanation
BOOTP is in your system's <b>/etc/services</b> file	BOOTP must be an uncommented line in the <b>/etc/services</b> file.
The NIC's name is in the loadhost's <b>/etc/hosts</b> file	The NIC's name must be in this file for the host to answer a BOOTP or TFTP request.
The download file is in the correct directory and is world-readable	The download file must be in the correct directory and world-readable. Specify the complete pathname for the download file in the BOOTP configuration file or, add a default pathname to the download filename.
The NIC and host are in the same IP network	Some hosts will not allow BOOTP replies across IP networks. Either use a host running a different operating system or put the NIC in the same IP network as the host.

## DHCP Troubleshooting

Area to Check	Explanation
DHCP is enabled on the NIC.	Use the <b>Define Server DHCP Enabled</b> command. If you manually enter an IP address, DHCP is automatically disabled.
Make sure the DHCP server is operational.	Check to see that the DHCP server is on and is functioning correctly.
Did the NIC get its IP address from the DHCP server?	Refer to the <b>DHCP Manager</b> on your Windows DHCP server for information about addresses currently in use. If the DHCP server does not list your NIC's IP address, there may be a problem.

## RARP Troubleshooting

Area to Check	Explanation
The NIC's name and hardware address in the host's <b>/etc/ethers</b> file	The NIC's name and hardware address must be in this file for the host to answer a RARP request.
The NIC's name and IP address in the <b>/etc/hosts</b> file	The NIC's name and IP address must be in this file for the host to answer a RARP request.
The operating system	Many operating systems do not start a RARP server at boot time. Check the host's RARPD documentation for details, or use the <b>ps</b> command to see if there is a RARPD process running.

## PostScript Problems

PostScript printers will silently abort jobs if they detect an error.

Area to Check	Explanation
The NIC is communicating with the printer	To test a PostScript printer use the <b>Test Port 1 PostScript Count 2</b> . This command will send 2 pages of PostScript data out the parallel port. Watch the indicators on the printer to verify that the NIC is communicating with the printer. If the printer is capable of bidirectional communication, use the <b>Test Service PRQLPSEPS_XXXXXX PS PostScript Count 5</b> command. This will transfer data both to and from the printer. Autoselection must be disabled and the printer must be configured as a PostScript printer for this test to succeed.



Area to Check	Explanation
Service Characteristics	Issue the <b>Show Service Characteristics</b> command. If the service rating is zero, the parallel port is in use. Verify that the PostScript characteristic and appropriate protocols have been enabled on the service.
Port Counters	If PostScript jobs appear to print but nothing comes out of the printer, verify the amount of data sent from the host. Issue the appropriate print command from the host system. After the job has completed, use the <b>Show Port 1 Counters</b> command.

## Bitmap Graphics

If files that contain embedded bitmap graphics print incorrectly, it is because the bitmaps are being sent as actual binary data and binary data cannot be printed via serial or parallel interfaces.

Most major application packages have provisions to print using either “binary postscript” (for printers connected to the network via LocalTalk) or “hex postscript” (for printers connected to the network via a serial port or parallel port). If your application does not have this provision, ask the application vendor for an upgrade version or “patch” that will add the “hex postscript” function.

## Technical Support

If you are experiencing an error that is not listed in the *Troubleshooting* appendix or if you are unable to fix the error, contact your point of purchase or Technical Support as listed in Appendix A.

When you report a problem, please provide the following information:

- Your name, and your company name, address, and phone number
- Printer model number
- Printer serial number
- Software version (use the **Show Server** command to display)
- Network configuration, including the information from a **Netstat** command
- Description of the problem
- **Debug** report (stack dump), if applicable
- Status of the unit when the problem occurred (please try to include information on user and network activity at the time of the problem).





# Appendix C

## Frequently Used Commands

### In this Chapter . . .

- [“About this Appendix” on page C-2](#)
- [“Server Commands” on page C-3](#)
- [“Protocol Commands” on page C-6](#)

## About this Appendix

This appendix lists some of the most frequently-used commands of the **Print** Server command set. More information about the command set, including additional options, can be found in the *Print Server Reference Manual* on the *Electronic Library* CD-ROM.

Please note the following before continuing:

- In this command set appendix the NIC is referred to as the Server.
- Commands are divided into Server (general), Port, and Protocol sections. Within each section, commands are listed alphabetically.
- Commands may require privileged user status. Enter `set Privileged`, then enter the privileged password when prompted.
- When you enter a Define or Purge command, you must reboot the Server for the command to take effect.
- When the abbreviated syntax “{EN|DIS}” is shown, you must choose either **Enabled** or **Disabled** to complete the command.

Each section lists additional information needed to use the command table in that section.

## Server Commands

Frequently-used Server Commands		
Command	Option(s)	Description
DEFINE SERVER BOOTP {EN DIS}		Enables or disables querying for a BOOTP host at system boot time.
DEFINE SERVER DHCP {EN DIS}		Enables or disables querying for a DHCP host at system boot time.
DEFINE SERVER GATEWAY ipaddress		Specifies the host to be used as a TCP/IP gateway to forward packets between networks. Enter an IP address.
DEFINE SERVER INCOMING <b>option</b>	BOTH	Enables incoming LAT and Telnet connections.
	LAT	Enables only incoming LAT connections.
	NONE	Disables incoming connections.
	TELNET	Enables only incoming Telnet connections.
	PASSWORD	Causes the server to prompt for a password for all incoming connections.
	NOPASSWORD	Allows connections to be established without prompting for a password.
DEFINE SERVER IPADDRESS ipaddress		Sets the Server's network IP address.
DEFINE SERVER LOADHOST ipaddress		Specifies the TCP/IP host from which the Server requests its run-time code.
DEFINE SERVER LOGIN PASSWORD		Sets a new password that will be required before incoming logins are accepted. You will be prompted for the new password (up to 6 alphanumeric characters, case-insensitive).
DEFINE SERVER NAME "newname"		Specifies a new name for the Server. Names are restricted in length; generally a name of 11 or fewer characters is permissible.
DEFINE SERVER NETWARE LOADHOST server		Specifies the NetWare host from which the Server requests its run-time code. Enter a file server name of up to 11 characters.
DEFINE SERVER PRIVILEGED PASSWORD		Sets a new password that will be required for privileged user status. You will be prompted for the new password (up to 6 alphanumeric characters, case-insensitive).
DEFINE SERVER RARP {EN DIS}		Enables or disables querying for a RARP host at system boot time.

Frequently-used Server Commands		
Command	Option(s)	Description
DEFINE SERVER SOFTWARE "filename"		Specifies the name or path (TCP) of the software download file. The filename can be up to 11 characters, and the pathname can be up to 26. The Server will add a ".SYS" extension.
DEFINE SERVER SUBNET MASK ipmask		Specifies the subnet mask to be used for the Server. The <code>ipmask</code> must be in <b>n.n.n.n</b> format.
HELP <b>option</b>	<nothing>	Displays a list of top-level (general) Help topics.
	<keyword>	Displays information about the keyword(s) entered. Multiple keywords must be specified in the order they occur in a command.
DEFINE SERVICE "name" PORT num		Creates a new service and associates it with the specified port.
DEFINE SERVICE "name" <b>option</b>	APPLETALK {EN DIS}	Toggles whether the named service can be used to service networks running the specified protocol. RTEL applies to TCP/IP networks.
	LANMAN {EN DIS}	
	LAT {EN DIS}	
	NETWARE {EN DIS}	
	RTEL {EN DIS}	
DEFINE SERVICE "name" <b>option</b>	BANNER {EN DIS}	When Enabled, causes the Server to print a banner page before jobs.
	BINARY {EN DIS}	When Enabled, the Server will not process data passed through the service. This characteristic should be enabled when printing PCL data.
	EOJ string	Causes the Server to send an end-of-job string to the attached device after every job. Enter an end string or the word <b>none</b> .
	FORMFEED {EN DIS}	When Enabled, causes the Server to append a formfeed to the end of LPR print jobs.
	PS CONVERT {EN DIS}	When Enabled, causes the Server to place a PostScript wrapper around each job.
	SOJ string	Causes the Server to send a start-of-job string to the attached device before every job. Enter a start string or the word <b>none</b> .

Frequently-used Server Commands		
Command	Option(s)	Description
DEFINE SERVICE "name" <b>option</b>	TCPPOINT string	Specifies a <i>raw</i> TCP listener socket for the service. Enter a socket number (4000 to 4999) or the word <b>none</b> .
	TELNETPORT string	Specifies a TCP listener socket for the service. Unlike TCPPOINT, this option performs Telnet IAC interpretation on the data stream. Enter a socket number (4000 to 4999) or the word <b>none</b> .
INITIALIZE <b>option</b>	DELAY num	Schedules a reboot after <i>num</i> minutes. Enter a value from 0 to 120.
	CANCEL	Cancels an impending initialization.
	FACTORY	Reboots the server to its factory default settings.
	NOBOOT	Forces the Server to stop in Boot Configuration Mode rather than fully rebooting.
	RELOAD	Forces the Server to download new operational code and reprogram its flash-ROM.
LOGOUT <b>option</b>	<nothing>	Logs out the current port (the port that issued the command).
	PORT num	Logs out the specified port.
PURGE SERVICE <b>option</b>	LOCAL	Removes the definitions of all local services.
	"service"	Removes the definition of the specified service.
SET PRIVILEGED		Enters privileged mode, provided the user enters the proper privileged password when prompted.
{SHOW MONITOR} QUEUE		Displays the status of Server queues once (Show) or continually every three seconds (Monitor).
{SHOW MONITOR} SERVER		Displays Server information once (Show) or continually every three seconds (Monitor).
{SHOW MONITOR} SERVICE <b>option</b>	<nothing>	Displays characteristics about all configured services once (Show) or continually every three seconds (Monitor).
	"service"	Displays only characteristics related to the named service.
ZERO COUNTERS <b>option</b>	ALL	Zeroes all port, node, and Server counters.
	PORT num	Zeroes port counters for the specified port.

## Protocol Commands

In the following table, `PROTO` is an abbreviation for the optional keyword `PROTOCOL`.

Protocol Commands		
Command	Option(s)	Description
DEFINE PROTO APPLETALK <b>option</b>	{EN DIS}	Enables or Disables the AppleTalk protocol for the Server.
	ZONE newzone	Places the Server in a zone other than the default.
DEFINE PROTO IP <b>option</b>	{EN DIS}	Enables or Disables the TCP/IP protocol for the Server.
	GATEWAY ipaddr	Same as <a href="#">“DEFINE SERVER GATEWAY ipaddress” on page C-3</a> .
	IPADDRESS ipaddr	Same as <a href="#">“DEFINE SERVER IPADDRESS ipaddress” on page C-3</a> .
	LOADHOST ipaddr	Same as <a href="#">“DEFINE SERVER LOADHOST ipaddress” on page C-3</a> .
	NAMESERVER ipaddr	Specifies the IP address of the host that will resolve text host names into their numeric equivalents for TCP/IP connection attempts.
DEFINE PROTO LAT <b>option</b>	{EN DIS}	Enables or Disables the LAT protocol for the Server.
DEFINE PROTO NETWARE <b>option</b>	{EN DIS}	Enables or Disables the NetWare (IPX) protocol for the Server.
	DSCONTEXT string	Configures the NetWare Directory Services context in which the Server is located. For more information about NDS contexts, see your NDS documentation.
	DSLICENSE string	Configures the NetWare Directory Services license needed to enable NDS on your Server. Enter the license string obtained from your dealer or Lantronix.
	DSTREE string	Configures the NetWare Directory Services tree in which the Server is located. For more information about NDS trees, see your NDS documentation.
DEFINE PROTO NETWARE ENCAPSULATION <b>option</b> {EN DIS}	NATIVE	Configures the Server to use the “native mode” frame format.
	ETHER_II	Configures the Server to use Ethernet v2 frame format.
	802_2	Configures the Server to use 802.2 frame format with NetWare SAPs.
	SNAP	Configures the Server to use 802.2 frame format with SNAP SAPs.



Protocol Commands		
Command	Option(s)	Description
DEFINE PROTO NETWARE LOADHOST server		Same as <a href="#">see “DEFINE SERVER NETWARE LOADHOST server” on page 3-3.</a>
PURGE PROTO NETWARE ACCESS <b>option</b>	ALL	Removes all entries from the NetWare access list.
	server	Removes entries from the NetWare access list that are related to the specified file server.
{SHOW MONITOR} protocolname		Displays operating characteristics of the specified protocol.



